



NOTES:

1. TEST SURFACE GRADE FOR STANDING WATER PRIOR TO INSTALLATION OF RESILIENT SURFACE.
2. INSTALL 3/4" WEEPING HOLES EVERY 3' AT LOWEST POINT OF SLOPE.
3. ALLOW APPROPRIATE CURE TIMES FOR THE CONCRETE BASE PER MANUFACTURES SPECIFICATIONS.
4. DO NOT USE AN ASPHALT BASE AS IT TENDS TO BE OILY AND WILL NOT PROVIDE A GOOD ADHESIVE SEAL.
5. RESILIENT TILE SHALL MEET THE ASTM 8' CRITICAL FALL HEIGHT PER THE MANUFACTURE'S SPECIFICATIONS.
6. APPLY ADHESIVE COAT TO ENTIRE SURFACE PRIOR TO INSTALLING RESILIENT TILES; AND APPLY ADHESIVE AT EACH JOINT PER MANUFACTURE'S SPECIFICATIONS.

SAFETY SURFACE RESILIENT TILE (TRANSITION)